

How to install a pad on the SPC-100 Manual Pad Printer



The Pad and the Pad Holder.



Put the Pad and the Pad Holder together.



Screw the Pad to the Pad Holder.



Loosen the Friction Screw with an allen wrench.



Inserting the Pad and Pad Holder.



Tightening it up. Ready to print.